

Frequenties

Voor radiobesturing van modelvliegtuigen mag gebruikt worden gemaakt van de volgende frequenties:

Frequentie Kleur Kanaalnr. Frequentie Kleur Kanaalnr.

27 MHz

26.995	Bruin	-
27.045	Bruin	9
27.095	Bruin	14
27.145	Bruin	19
27.195	Bruin	24

30 MHz

30.085	Geel	38
30.095	Geel	39
30.105	Geel	40
30.115	Geel	41
30.185	Geel	48
30.195	Geel	49

35 MHz

35.000	Oranje	260
35.010	Oranje	61
35.020	Oranje	62
35.030	Oranje	63
35.040	Oranje	64
35.050	Oranje	65
35.060	Oranje	66
35.070	Oranje	67
35.080	Oranje	68
35.090	Oranje	69
35.100	Oranje	70
35.110	Oranje	71
35.120	Oranje	72
35.130	Oranje	73
35.140	Oranje	74
35.150	Oranje	75
35.160	Oranje	76
35.170	Oranje	77
35.180	Oranje	78
35.190	Oranje	79
35.200	Oranje	80
35.210	Oranje	281
35.220	Oranje	282

40 MHz

40.665	Groen	50
40.675	Groen	51
40.685	Groen	52
40.695	Groen	53
40.715	Groen	54
40.725	Groen	55
40.735	Groen	56
40.765	Groen	57
40.775	Groen	58
40.785	Groen	59
40.815	Groen	81
40.825	Groen	82
40.835	Groen	83
40.865	Groen	84
40.875	Groen	85
40.885	Groen	86
40.915	Groen	87
40.925	Groen	88
40.935	Groen	89
40.965	Groen	90
40.975	Groen	91
40.985	Groen	92

2,4 GHz